


JETWOOD®




1:18 RC HIGH SPEED CAR USER MANUAL



 CA Store



 USA Store

 <https://www.jetwoodtech.com>
 customerservice@jetwoodtech.com (USA Market)
 cacs@jetwoodtech.com (CANADA Market)

4WD
REMOTE CONTROL

The instruction sheet for this product is just for your reference. We reserve the right to make changes or adjustments on the product without prior notification. Please refer to the official information.

Warning:

Choking hazard! This product contains small parts. NOT suitable for children under 3 years. Contains electrical components and should be kept dry at all times. Regularly check the battery charger wires, plugs and shell and other components for damage. DO NOT use if any part is damaged.

Warnings & Cautions

1. Detachable small parts should be stored safely and out of reach of children.
2. If interference is experienced, turn the model off and try it again in a different area.
3. Transmitter will not function correctly if the batteries are low. Please replace the batteries.
4. Please discard old/used batteries in a safe manner. Consider your environment!
5. Please store the remote control model in cool, dry place.
6. DO NOT expose to fire or high temperatures, do not store in moist place.
7. Once the battery get wet, wipe immediately with a soft dry cloth.
If the battery any deformation, please stop using.
8. If you don't use the model for a long time, please raise the chassis to let the wheels hang in the air.

Precautions for Battery Use

1. Transmitter uses 4x1.5V "AA" batteries.
2. Please pay attention to correct polarity when replacing batteries.
3. Rechargeable batteries should be charged under adult supervision.
4. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
5. After the battery is exhausted, the model should be removed.
6. Exhaust battery should be safety dispose!
7. DO NOT short circuit any terminals.
8. DO NOT attempt to recharge non rechargeable batteries.
9. Remove batteries from the model when charging.
10. DO NOT put batteries into a fire or into water.
11. The rated input voltage battery charger MUST be suitable for your mains power voltage.
12. During charging it is quite normal for the charger and batteries to heat up.
13. Do not swallow battery!
14. Store only in cool, dry and dark places and should be keep out of the children!
15. When the battery leaks the liquid and let it into you eyes, please right away rinse them and consult an ophthalmologist.

Safety Precautions

- It is a radio control model, not a toy!
- In order to enjoy running the car, you need to finish assembly before operation. Do routine maintenance work after operation. Replacement parts and option parts are available separately.
- Improper usage with Alkaline cells or rechargeable batteries may damage the electronics for the car or the radio.

In order to operate the car safely. Be sure that you have observed the following points:



Please follow the points as below in order to prevent accident from happening to the car and people.



- Be sure to read thoroughly the manual before you begin. Fresh user should seek advice from people having rich experience in order to assemble the model correctly.




- Cutters, nippers and screwdrivers need careful handling.



- As the product contains small and sharp parts, assemble and store this product only in places out of the reach of children.



- Do not expose this model to high temperature, humidity or direct sunlight.



- Never reverse connection/ disassemble the battery. This may lead to damage and leakage.

- When the model is not in use, always turn off the receiver and transmitter. Further more, disconnect the batteries and remove them from the model and the transmitter. This may be dangerous such as overheat and leakage.

Operating Your Model Safely

⚠ Do NOT operate the model in the following places and situations. (Non-observance may lead to accident!)

- Operate your model in spacious and safe areas! Do not operate it:
 1. On road!
 2. In places where children and many people gather.
 3. In residential districts and parks!
 4. Do not operate the model on public roads, in crowded places and near infant as it may cause accidents.
 5. Indoors and in limited space! Non-observance may result in personal injury and property damage!
- The car must stop immediately and check for the reasons when it is operating abnormal. As long as the problem is not cleared, do NOT operate it! This may lead to further trouble and unforeseen accidents!
- Always check the radio batteries!
With weak dry batteries, transmission and reception of the radio would fall off. You may lose control of your model in such condition. This may also cause serious accidents!
- Keep in mind that people around you may also operate a radio control model!
NEVER share the same frequency with somebody else at the same time! Otherwise, Radio signals will be mixed up and you will lose control to your model. This may lead to accidents.
- Do NOT put fingers or any objects inside rotating and moving parts!
- Right after use, do NOT touch the motor! Danger of burning yourself!



FCC PART 15 B Notice: CAUTION

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.


Install the Transmitter's Battery

Open the transmitter's battery cover, insert 4 AA batteries according to the indicated positive and negative direction, close the battery cover.




Install the Battery

- ① Tighten the battery with the fixing tape;
- ② Connect the receiver plug to the battery.



①




②

Charge



It is recommended to use a 5V 2A adapter for charging.

- When the battery is charging, the red indicator light of the charging cable is always on and the green indicator light is flashing;
- When the battery is fully charged, the red indicator light of the charging cable is always on and the green indicator light is always on.



Power Switch


- 1. Turn on the power switch of the transmitter, the signal indicator light of transmitter flashes.
- 2. Press the power button of high speed car, the indicator light of high speed car flashes.
- 3. When the indicator light stays on, the high speed car can be operated to play.



- ⚠ •When turn on the transmitter, please DO NOT touch the throttle and steering. After turn on the transmitter's power, please operate after the indicator light of transmitter staying on.
- Please comply the principle of “turn on the transmitter firstly, then turn on the high speed car”.
- In the frequency matching, please make sure there is only one pair of transmitter and high speed car in matching at the same time, otherwise the frequency will match wrongly.



2-in-1 ESC & REV

⚠ Please Do Not forcible/reversely insert all sockets.




Indicator light situation	Meanings
Stays on	Signaled
Flash quickly	a. No signal b. Pull the trigger
Flash slowly	Low voltage
Flash twice	Over heat protection
Off	Stuck protection

T3E Transmitter



①ST.TRIM (Steering servo trimmer)


If the car cannot go straightly during driving, it can be adjusted through the ST.TRIM.



②TH.TRIM (Throttle trimmer)

If the car can't be stop when the TH in the middle place, you can adjust the button to stop the car.

Forward



③Indicator light


Stays on	Working well
Flash quickly	Frequency mating
Flash slowly	Low battery of transmitter

④CH1: ST (Steering)



Middle

Turn left

Turn right



⑤CH2: TH (Throttle)




Brake: When the car is going forward, pull the transmitter trigger back, and the car enters into the braking state. After the trigger is in the middle, push back again, and the car can move backward.


*When the car is in reverse situation, it does not the brake function.

Install Car Shell


1. Insert the housing into the front shock absorber frame ①, and then press it down vertically onto the rear shock absorber frame latch ②.



2. Turn the knob to lock the housing ③.



High Speed Car Exploded View



Spare Parts

JW1801	Body	1 Pcs
P181000	Chassis	1 Pcs
P181100	Front Bumper	1 Pcs
P181110	Rear Bumper	1 Pcs
P181160	Front /Rear Gearbox Covers	1 Set
P181210	Rear Upper Suspension Arms	1 Pair
P181220	Front Lower Suspension Arms	1 Pair
P181230	Steering Block	1 Pair
P181240	Front Upper Suspension Arms	1 Pair
P181250	Rear Lower Suspension Arms	1 Pair
P181260	Rear Hubs	1 Pair
P181270	Servo Fix Frame	1 Pcs
P181300	Wheel Assembly	4 Pcs
P181310	Center Brace	1 Pcs
P181400	Main Driving Set	1 Set
P18141F	Front Tire Shaft Set	2 Pcs
P18141R	Rear Tire Shaft Set	2 Pcs
P181420	Diff Assembly	1 Pcs
P181430	Steering Assembly	1 Set
P181440	Wheel Hex	4 Pcs
P181500	Shock	2 Pcs
X16701	Servo	1 Pcs
P181702	Servo Saver Assembly	1 Set
P18138S	Motor Assembly	1 Set
XRE30	REV & 30A ESC	1 Pcs
XB2S15K	Battery	1 Pcs
XM2523	Pins Ø2.5*23mm	4 Pcs
XM2537	Pins Ø2.5*37mm	4 Pcs

Screws

XHHM2570	M2.5*7mm	12PCS
XHHM25120	M2.5*12mm	12PCS
XHHM2550	M2.5*5mm	12PCS
XHPHM25160	2.5*16/M3*4mm	12PCS
XHPHM25250	2.5*25/M3*4mm	12PCS
XHKM25120	M2.5*12mm	12PCS
XHKM2580	M2.5*8mm	12PCS
XMHWB26120A	2.6*12mm	12PCS



 CA Store



 USA Store

 <https://www.jetwoodtech.com>

 customerservice@jetwoodtech.com (USA Market)

 cacs@jetwoodtech.com (CANADA Market)



MADE IN CHINA

Instructions must be retained since it contains important information.